

Measuring Model Properties

Measuring distance:

- 1. Open robot_system.asm.
- 2. From the Analysis tab, click **Measure** *P*.



3. Choose **Measure: Distance** in the pop-up window.

Measure	: Distance	х
		θ

4. Press and hold the Ctrl key and click two points on the model to select them.

Creo calculates the distance of the points in the model. The graphic shows the width of the claw mechanism.

There are several measurement tools available. You can measure length, angle, diameter, surface area, volume, etc.



Calculating mass:

- 1. Select Mass Properties a.
- 2. Click **Preview** to calculate the properties.

The first time you use Mass Properties for a model the Density window appears showing the default density of each part.

If your parts don't have an assigned material or density, they will be given the default density. You are able to change it to a more precise value.

If you leave the defaults, you may make your model too heavy to run accurate simulations.

3. Click **OK** to calculate properties using the set values.

Notice the physical properties calculated.

These properties are calculated using the material information that has been provided or defaulted for each of the parts used in the assembly.

We will talk about how to validate or test these calculations in the next exercises.

4. Click on **Mass Properties** again to close the Measure tool.



		Mass Prop	erties		×
Analysis	Feature				
 Solid Quilt: 	geometry				
Coordina	te system:	Select	items		
		Y Use a	erault		
Density:	1.000	000e+00			¥
Accuracy	r: 0.000	001000			Ŧ
Com VOLUMI SURFAC AVERAC MASS = CENTER X Y Z	puted E = 1.4584 CE AREA = GE DENSIT 8.751512 R OF GRAV -2.71102	(4565e+02 1.972054 TY = 6.000 (2e+00 POL 2e+00 POL 216e-02 3.5) Assigned NCH ^A 3 5e+03 INCI 5301e-02 P JND spect to _F 5061247e+0	H ^A 2 OUND 00-5.41	1
Quick	Mass	s_Prop_1			
Preview	Repe	at	Oł	(Ca	ncel

ptc academic program

Questions or ideas? Drop us a note at <u>FIRST@ptc.com</u>. Twitter: @PTC_FIRST Facebook: @ptcfirst

nikin	Tools	View	Applic	ations	Frame	work
🔔 Ma	ss Propert	ies 🔻	LILLIH .		1	
🚊 Sho	ort Edge		ALL	ահահահահա	<u>∕</u> •	ulululuu Chandau
🞬 Thio	kness		Ivleasure	Properties	Angle	Shadow

ORE_DEVICE_INTERFACE.P	1.1.000000	
	1.000000	IDM / IN*3
ORE_MOTOR_CONTROLLE	1.000000	Ibm / in^3
ORE_POWER_DISTRIBUTIO	1.000000	lbm / in^3
ORE_SERVO_CONTROLLER	. 1.000000	lbm / in^3
ETRIX_39593_SCALE_PIVOT	1.000000	kg / mm^3
ETRIX_739107_2013.PRT	1.000000	kg / mm^3
ETRIX_739177_CR_SERVO_4	. 1.000000	kg / mm^3
ETRIX_739270_2013.PRT	1.000000	kg / mm^3
		*